

## B-Smart Refueling System

SI

DRIVER AUTH CODE

Drivers cannot access fuel unless they have downloaded the B-Smart app to their mobile device.

Please download from the Google Play Store or Apple App store by searching **Piusi B.smart** and downloading the app.



APPLE



ANDROID

### Set Up On the Drivers Phone.....

- Download the B.Smart App and make sure **Bluetooth Enabled** and you have either **WiFi or a 3G/4G Data**
- Open the App
- Driver login box should appear
- Enter your assigned Authentication/PIN Code in the box provided.....exactly as it was put into the B.Smart Portal. It won't work if not.
- Enter the Site Code – Only required once to set the APP up (See Site ID top of the page)
- App should now open completely and say welcome <DRIVER NAME

- Driver is now ready to dispense from the menu -



### Driver Refuelling via phone app.....

- Open app – make sure **Bluetooth Enabled** and you have either **WiFi or a 3G/4G Data**
- Welcome message on the screen for the driver
- Approach the pump
- Select Dispenser name from list and the panel will light up.
- Start typing vehicle REG number and if it's registered, it will show up in a list / use drop down to select
- Enter Odometer if asked. Cannot be less than the last figure entered.
- Either click the REFILLING button to start or enter a pre-set quantity.

Once refuelling has commenced the display will count the litres dispensed as well as the phone. This will work up to 15m away from the dispenser so the phone can be left in the car whilst refuelling if need be.

Once Refuelling has been completed a ticket will be displayed on the phone and the refuelling data will be sent to the cloud.

## B-Smart Refueling System

SI

DRIVER AUTH CODE

Drivers cannot access fuel unless they have downloaded the B-Smart app to their mobile device.

Please download from the Google Play Store or Apple App store by searching **Piusi B.smart** and downloading the app.



APPLE



ANDROID

### Set Up On the Drivers Phone.....

- Download the B.Smart App and make sure **Bluetooth Enabled** and you have either **WiFi or a 3G/4G Data**
- Open the App
- Driver login box should appear
- Enter your assigned Authentication/PIN Code in the box provided.....exactly as it was put into the B.Smart Portal. It won't work if not.
- Enter the Site Code – Only required once to set the APP up (See Site ID top of the page)
- App should now open completely and say welcome <DRIVER NAME

- Driver is now ready to dispense from the menu -



### Driver Refuelling via phone app.....

- Open app – make sure **Bluetooth Enabled** and you have either **WiFi or a 3G/4G Data**
- Welcome message on the screen for the driver
- Approach the pump
- Select Dispenser name from list and the panel will light up.
- Start typing vehicle REG number and if it's registered, it will show up in a list / use drop down to select
- Enter Odometer if asked. Cannot be less than the last figure entered.
- Either click the REFILLING button to start or enter a pre-set quantity.

Once refuelling has commenced the display will count the litres dispensed as well as the phone. This will work up to 15m away from the dispenser so the phone can be left in the car whilst refuelling if need be.

Once Refuelling has been completed a ticket will be displayed on the phone and the refuelling data will be sent to the cloud.