






















































































<b>FUNCTIONALITY</b> 			
Limits pump access to authorised drivers	 Pin code/electronic key	 Pin code/electronic key	 Smartphone app/electronic backup key
Records user, date, time, QTY of fuel, pump			
Preset dispensing or complete fill			
Record vehicle registration & odometer reading			
Remotely enable/disable drivers			
Set driver controls (QTY of fuel, working hours, vehicles they can refill)			
Add external fills at service station			
<b>REPORTING</b> 			
View data and reports on PC			
Data viewable by graph or table			
Filter reports by date, driver, vehicle, pump			
Export reports to .pdf, .xlsx or .txt			
Customisable .txt reports			
Live real-time reports			
Fuel consumption reports by driver/vehicle			
Remote access from any device with internet	 Local PC only	 Local PC only	 Cloud based portal
<b>DATA TRANSFER &amp; STORAGE</b> 			
No ongoing hosting fees			
Automatic data transfer	 Manual download onto USB	 Manual download onto USB	 Via mobile network
Remote data transfer	 Must visit each site/pump	 Must visit each site/pump	 Via mobile network
<b>TANK LEVEL MONITORING</b> 			
Virtual tank levels (deliveries manually added)			
Fuel inventory value		 Uses last delivery cost	 Calculates average cost
Live tank levels			
Low tank level alerts		 Visual alert in software	 Visual alert in portal + email alerts
<b>COMPANY SIZE</b> 			
Unlimited number of vehicles			
Unlimited number of pumps	 Maximum 16	 Maximum 16	
Unlimited number of sites	 Maximum 16	 Maximum 16	
Unlimited number of drivers	 Maximum 120	 Maximum 250	 Up to 500 per pump
<div> <div>  It is possible to run a cable from pump to PC to make data transfer automatic, but often not viable on site. </div> <div>  With add on module. </div> <div>  Tank data is only live as per the last data sync. </div> </div>			