

PRODUCT GUIDE

Piusi OCIO Fuel Tank Gauge



Please note: these instructions do not replace the use and installation manual


1. Quick Startup Guide

- » Startup OCIO system
- » Log into the configuration menu




2. Fastening Ocio

To secure Ocio to the wall, use the screws that can be accessed after moving the front panel.



3. Linking Ocio

- » Connect the power supply
- » Connect the probe tube
- » Connect the alarm (optional)
- » Connect the pc cable (optional)



4. Log into configuration menu

Retrieve the serial number by pushing the CANCEL button to display it. Then, enter the pin code (which corresponds to the last two digits of the serial number) to access the configuration menu by using up/down keys.



All other instructions are available in the use and installation manual.