






 3680 W	 2300 VA
 1800 W	 1800 W
 60 W 7μF	 1200 W
 2300 W	 60 VA



NT292723/00

④



Change switching days

⑦



4/



DEL C1/2 -> Delete the programs for a channel

⑤



SERIAL -> Switching commands in chronological order

⑥

Mode PERManent



Reset



The time, date, summertime/wintertime and switching times will have to be re-entered.

Always use a Li cell type battery (Li) CR2032, 3V. High temperature type min +70°C.

